



MAESTRO GPS - APPS NOTE

GPSC3 FIRMWARE REV 0.1

A DESCRIPTION OF USEFUL MODES SUPPORTED VIA THE SIRF BINARY PROTOCOL
ON MAESTRO WIRELESS SOLUTIONS'S GPS MODULES BASED ON SIRF III - GSC3
A1080A, A1084, A1088A, A1035H
FIRMWARE 3.6.0

WWW.MAESTRO-WIRELESS.COM

EMAIL: CONTACT@MAESTRO-WIRELESS.COM

TEL: (+852) 2869 0688

FAX: (+852) 2525 4701

ADDRESS: ROOM 3603-3609, 36/F, 118 CONNAUGHT ROAD WEST, SHEUNG WAN, HONG KONG

Revision history

Rev.	Date	Details	Originated by
0.0	22 March 2011	First issue	Samuel Chereau
0.1	6 April 2011	CSR approved. Updated for revision 3.6.0 FW.	Samuel Chereau

This manual is written without any warranty.

Maestro Wireless Solutions Ltd. reserves the right to modify or improve the product and its accessories which can also be withdrawn without prior notice.

Besides, our company stresses the fact that the performance of the product as well as accessories depends not only on the proper conditions of use, but also on the environment around the places of use.

Maestro Wireless Solutions Ltd. assumes no liability for damage incurred directly or indirectly from errors, omissions or discrepancies between the modem and the manual.

Contents

1 Introduction	4
2 NMEA and Binary mode	5
2.1 From NMEA to Binary Mode	5
2.2 From Binary to NMEA Mode	6
2.3 SiRFDemo Software	7
3 Push-To-Fix Mode	8
3.1 Necessary Steps	8
3.1.1 Set Trickle Power Parameters – Message ID 151	8
3.1.2 Set Low Power Acquisition Parameters – Message ID 167	9
3.2 Exit Push-To-Fix Mode	10
3.3 Summary of Main Advantages	11
4 SBAS Support	12
5 Static Mode	13
6 Shutdown Module	15
7 Related Information	16
7.1 Contact	16
7.2 Related Documents	16
7.3 Related Tools	17

List of Tables

2.1	Serial Port Setup	5
3.1	Set trickle power mode parameters (enter) – Message ID 151	9
3.2	Set low power acquisition parameters – Message ID 167	9
3.3	Push-to-fix mode examples	10
3.4	Set trickle power mode parameters (exit) – Message ID 151	10
4.1	DGPS source selection – Message ID 133	12
5.1	Static Navigation enable – Message ID 143	13
5.2	Navigation disable – Message ID 143	14
6.1	Shutdown module – Message ID 205	15

Chapter 1

Introduction

The intention of the application notes described in this document is to help customers make use of the most important features of Maestro Wireless Solutions's SiRFstarIII - GSC3-based products. This document is a living document; it mostly explains the software commands necessary to support the different features but also tries to explain the background of these features.

Chapter 2

NMEA and Binary mode

By default Maestro Wireless Solutions receivers start off in NMEA mode. You can get the well known NMEA sentences, switch them on or off - but not much more. In order to go deeper into the SiRFstarIII configuration, it is necessary to switch to binary mode.

2.1 From NMEA to Binary Mode

This is done using the following NMEA command (note that the baud rate can be different):

– \$PSRF100,0,57600,8,1,0*37

Refer to the Table 2.1 for a more general description on the PSRF100 command that allows switching to SiRF binary protocol.

Name	Example	Description
Message ID	\$PSRF100	PSRF100 protocol header
Protocol	0	0 SiRF binary / 1 NMEA
Baud	57600	4800, 9600, 19200, 38400, 57600, 115200
DataBits	8	8, 7
StopBits	1	0, 1
Parity	0	0 none / 1 odd / 2 even
Checksum	*37	End of message termination

Table 2.1: Serial Port Setup

After that information from the module and commands to the module are transmitted in SiRF binary protocol mode. For details please refer to the according manual.

This command has no impact on the serial port used. All data exchange will be done via port 0.

If backed by a battery (Vbak), the module will store the configuration and reboot after a reset in the very same way. If completely powered off, the module will start in default NMEA mode again.

2.2 From Binary to NMEA Mode

When you configured the module you might wish to go back to NMEA mode in order to get the PVT information in the standard, familiar way. In order to do that, you can use the following binary command sequence:

A0A200188102010100010101010101010001000100010001000112C00163B0B3

Within this message one can determine the following segments (this applies generally to all SiRF binary commands):

A0A20018 – Start Sequence (A0A2) and Payload Length (0x18 = 24)
 8102 0101 0001 0101 0101 0101 0001 0001 0001 0001 0001 12C0 – Payload
 0163B0B3 – Message Checksum (0163) and End Sequence (B0B3)

Name	Bytes	Example	Unit	Description
Message ID	1U	0x81		Decimal 129
Mode	1U	0x02		Do not change last-set value for NMEA debug
GGA Message ^a	1U	0x01	s	See NMEA Protocol Reference Manual for format
Checksum ^b	1U	0x01		Send checksum with GGA message
GLL Message	1U	0x00	s	See NMEA Protocol Reference Manual for format
Checksum	1U	0x01		
GSA Message	1U	0x01	s	See NMEA Protocol Reference Manual for format
Checksum	1U	0x01		
GSV Message	1U	0x01	s	See NMEA Protocol Reference Manual for format
Checksum	1U	0x01		
RMC Message	1U	0x01	s	See NMEA Protocol Reference Manual for format
Checksum	1U	0x01		
VTG Message	1U	0x00	s	See NMEA Protocol Reference Manual for format
Checksum	1U	0x01		
MSS Message	1U	0x00	s	Output rate for MSS message (always zero, as not supported here)
Checksum	1U	0x01		
Unused field ^c	1U	0x00		
Unused field	1U	0x01		
ZDA Message	1U	0x00	s	See NMEA Protocol Reference Manual for format
Checksum	1U	0x01		
Unused field	1U	0x00		
Unused field	1U	0x01		
Bit rate	2U	0x12C0		1200, 2400, 4800, 9600, 19200, 38400, and 57600

Switch to NMEA mode – Message ID 129

^aA value of 0x00 implies not to send message, otherwise data is sent at 1 message every X seconds re-quested (e.g., to request a message to be sent every 5 seconds, request the message using a value of 0x05). Maximum rate is 1/255 sec.

^bA value of 0x00 implies the checksum is not transmitted with the message (not recommended). A value of 0x01 has a checksum calculated and transmitted as part of the message (recommended).

^cThese fields are available if additional messages have been implemented in the NMEA protocol.

So this command would result in switching to NMEA mode with a baud rate of 4800 bits per second and the following configuration:

GGA – ON at 1 sec, GLL – OFF, GSA – ON at 1sec, GSV – ON at 1 sec, RMC – ON at 1sec, VTG - OFF, MSS – OFF, ZDA - OFF.

After that information from the module and commands to the module are transmitted in NMEA format again.

For details please refer to the according manual.

This command has no impact on the serial port used. All data exchange will be done via port 0.

If backed by a battery (Vbak), the module will store the configuration and reboot after a reset in the very same way. If completely powered off, the module will start with the default NMEA settings.

2.3 SiRFDemo Software

A useful tool to test and evaluate SiRF binary commands is the SiRFDemo Software. This tool is available from Maestro Wireless. Please contact your local sales representative if you should need this tool. Detailed information about the tool is available in the SiRFDemo User Guide.

Chapter 3

Push-To-Fix Mode

The goal of using this mode is to keep the receiver always in a state where it has more or less the latest satellite information (Ephemeris data) – after initialization without any further external engagement. When then finally being awakened by an external microcontroller the receiver can perform a hot start with a very short time to fix. Along with the sleep cycles this will result in an excellent power budget.

Initialized to this mode the receiver turns on every cycle period to perform a system update consisting of an RTC calibration and satellite ephemeris data collection if required. This is the case when a new satellite has become visible or validity of old Ephemeris data did expire. In addition it performs all software tasks to support a quick fix request in the event of a Non-Maskable Interrupt (NMI). If Ephemeris data collection is not required then the system recalibrates and shuts down. Ephemeris collection time in general takes 18 to 36 seconds. A fix request is initiated by toggling the module's ON_OFF pin (see also: Receiver Manual) – resulting in an internal NMI. Note that the toggling should be performed only when RFPWUP is low, i.e. when the receiver is sleeping. When a fix request was initiated the module will calculate at least one fix, try to update Ephemeris data and go back to sleep.

3.1 Necessary Steps

To put the receiver into push-to-fix mode, two commands are necessary. First of all, the receiver has to be brought into push-to-fix mode using the trickle power mode command. Anyhow, one has to see that trickle power mode and push-to-fix mode are two different things! In a further step push-to-fix parameters have to be defined.

3.1.1 Set Trickle Power Parameters – Message ID 151

```
A0A2000997000103E8000000C8024BB0B3
```

Within this message one can determine the following segments, refer to the Table 3.4:

```
A0A20009 – Start Sequence (A0A2) and Payload Length (0x09 = 9)  
97000103E8000000C8 – Payload  
024BB0B3 – Message Checksum (024B) and End Sequence (B0B3)
```

Name	Bytes	Scale	Example	Unit	Description
Message ID	1U		0x97		Decimal 151
PTF Mode	2S		0x0001		0 = OFF, 1 = ON (here)
Duty Cycle	2U	*10	0x03E8	%	% time ON. A duty cycle of 1000 (100%) means continuous operation. Here: 1000. ▲ Trickle power mode settings are unused!
On time	4U	*10	0x000000C8	ms	Allowed range 200 – 900ms. Here: 200ms. ▲ Only used, when duty cycle is different from 1000, so meaningless here!

Table 3.1: Set trickle power mode parameters (enter) – Message ID 151

So this way we tell the receiver to switch to push-to-fix mode.

3.1.2 Set Low Power Acquisition Parameters – Message ID 167

A0A2000FA70001D4C0000075300000012C0000030EB0B3

Within this message one can determine the following segments, refer to the Table 3.2 :

A0A2000F – Start Sequence (A0A2) and Payload Length (0x0F = 15)

A70001D4C0000075300000012C0000 – Payload

030EB0B3 – Message Checksum (030E) and End Sequence (B0B3)

Name	Bytes	Scale	Example	Unit	Description
Message ID	1U		0xA7		Decimal 167
Max. Off Time	4S		0x0001D4C0	ms	Max. time for sleep mode, default 30s, here 120000ms = 120s
Max. Search Time	4U		0x00007530	ms	Max. satellite search time, default 120s, here 30000ms = 30s
Push-to-fix Period	4U		0x0000012C	s	Push-to-fix cycle period, here 300s
Adaptive T.P.	2U		0x0000	s	▲ Always 0!

Table 3.2: Set low power acquisition parameters – Message ID 167

Maximum Off Time

The receiver turns on after the maximum off time, if the receiver could not catch satellite signals within the maximum search time during the last attempt.

Maximum Search time

This is the maximum time period the receiver tries to catch satellite signals. The receiver will go back to stand-by if the receiver cannot receive satellite signals within this period and will try it again after the maximum off time.

PTF Period

This is the PTF cycle period. The receiver turns on automatically to perform a system update.

Examples - Table 3.3

Parameters			Command (Hexa)	Comment
Max. Off Time (s)	Max. Search Time (s)	PTF Period (s)		
120	30	300	A0A2000FA70001D4C0000075 300000012C0000030EB0B3	Test setting
1800	30	1800	A0A2000FA7001B7740000075 30000007080000022DB0B3	SiRF recommended default setting
2100	30	4200	A0A2000FA700200B20000075 30000010680000020FB0B3	Test setting

Table 3.3: Push-to-fix mode examples

3.2 Exit Push-To-Fix Mode

To exit from push-to-fix mode, the according command needs to be sent while the receiver is awake. If the receiver is awake can be detected by checking if anything (NMEA or binary information) is transmitted by the receiver or by looking at the pins RFWUP (High = ON) or nWakeup (Low = ON). Naturally, the receiver will be also awake after a fix request (toggling of ON_OFF pin) was done.

The following message will bring back the receiver to normal operation. Of course the receiver needs to be put into binary command mode before.

A0A2000997000003E8000000C8024AB0B3

Within this message one can determine the following segments, refer to the Table 3.4:

A0A20009 – Start Sequence (A0A2) and Payload Length (0x09 = 9)
 97000003E8000000C8 – Payload
 024AB0B3 – Message Checksum (024A) and End Sequence (B0B3)

Name	Bytes	Scale	Example	Unit	Description
Message ID	1U		0x97		Decimal 151
PRF Mode	2S		0x0000		0 = OFF (here), 1 = ON
Duty Cycle	2U	*10	0x03E8		% time ON. A duty cycle of 1000 (100%) means continuous operation. Here: 1000. ▲ Don't use any trickle power mode settings!
On Time	4U	*10	0x000000C8		Allowed range 200 – 900ms. Here: 200ms. ▲ Only used, when duty cycle is different from 1000, so meaningless here!

Table 3.4: Set trickle power mode parameters (exit) – Message ID 151

3.3 Summary of Main Advantages

The push-to-fix mode gives the following advantages:

- One initialization – no further engagement from external microcontroller
- Receiver is always up-to-date with Ephemeris data (of course, if satellites are „visible“)
- Whenever awakened it is ready for a hot start
- This results in a minimum TTFF
- Total power budget optimized

Chapter 4

SBAS Support

The SiRFstarIII chip set supports the Satellite Based Augmentation System (SBAS) a kind of Differential GPS (DGPS) via satellite. The advantage of SBAS towards traditional DGPS lies in the fact that correctional data are received on a normal GPS channel. Therefore the receiver can use one of its 20 channels to detect and decode SBAS information. There is no need for an additional external receiver.

To initialize SBAS mode it is necessary to send the message with ID 133 (DGPS source) to the receiver – which has to be put into binary mode before.

A0A20007850100000000000086B0B3

Within this message one can determine the following segments, refer to the Table 4.1:

A0A20007 – Start Sequence (A0A2) and Payload Length (0x07 = 7)
 8501000000000000 – Payload
 0086B0B3 – Message Checksum (0086) and End Sequence (B0B3)

Name	Bytes	Scale	Example	Unit	Description
Message ID	1U		0x85		Decimal 133
DGPS Source	1U		0x01		0 = None 1 = SBAS (here) 2 = External RTCM data 3 = Internal DGPS beacon receiver 4 = User software
Internal beacon frequency	4U		0x00000000		Not used!
Internal beacon bit rate	1U		0x00		Not used!

Table 4.1: DGPS source selection – Message ID 133

By default the receiver will find the right SBAS satellite automatically. One can select a specific SBAS satellite using message ID 170. Please refer to the SiRF Binary Reference Manual for details.

Chapter 5

Static Mode

Static navigation is a position filter designed to be used with applications intended for motor vehicles. When the vehicle's speed falls below a threshold, the position and heading are frozen, and speed is set to zero. This condition continues until the computed speed rises above 1.2 times the threshold or until the computed position is at least a set distance from the frozen place. The threshold speed and set distance may vary with software versions, currently the thresholds are as follows:

- Speed: ~ 3km/h
- Position: ~ 50m

These thresholds are fixed and cannot be modified by the user. Also, with the static mode one cannot reach a higher accuracy! But one will avoid small jumps due to the "noise" in the GPS signals and receiver.

To initialize static mode it is necessary to send the message with ID 143 to the receiver – which has to be put into binary mode before.

A0A200028F010090B0B3

Within this message one can determine the following segments, refer to the Table 5.1:

A0A20002 – Start Sequence (A0A2) and Payload Length (0x02 = 2)
 8F01 – Payload
 0090B0B3 – Message Checksum (0090) and End Sequence (B0B3)

Name	Bytes	Scale	Example	Unit	Description
Message ID	1U		0x8F		Decimal 143
Static Navigation Flag	1U		0x01		0 = Enable (here) 1 = Disable

Table 5.1: Static Navigation enable – Message ID 143

To disable static mode, the according command would be:

A0A200028F00008FB0B3

Within this message one can determine the following segments, refer to the Table 5.2:

A0A20002 – Start Sequence (A0A2) and Payload Length (0x02 = 2)
 8F00 – Payload
 008FB0B3 – Message Checksum (008F) and End Sequence (B0B3)

Name	Bytes	Scale	Example	Unit	Description
Message ID	1U		0x8F		Decimal 143
Static Navigation Flag	1U		0x00		0 = Enable 1 = Disable (here)

Table 5.2: Navigation disable – Message ID 143

Chapter 6

Shutdown Module

This command is available starting with firmware version 3.5.0 only!

All GSC3-based GPS modules will enter hibernate mode after this command has been issued. Data in SRAM are being maintained, the RTC will keep on running.

To shutdown the module it is necessary to send the message with ID 205 along with Sub ID 16 to the receiver – which has to be put into binary mode before.

A0A20002CD1000DDB0B3

Within this message one can determine the following segments:

A0A20002 – Start Sequence (A0A2) and Payload Length (0x02 = 2)

CD10 – Payload

00DDB0B3 – Message Checksum (00DD) and End Sequence (B0B3)

Name	Bytes	Scale	Example	Unit	Description
Message ID	1U		0xCD		Decimal 205
Message Sub ID	1U		0x10		Message Sub ID for software command off

Table 6.1: Shutdown module – Message ID 205

Note: The SiRF Binary Manual shows a payload length of 0 bytes. This is incorrect. Please use the payload length of 2 bytes as described here.

To wake up the GPS module again one of the following methods can be used:

- Toggle ON-OFF
- Toggle nReset

Chapter 7

Related Information

7.1 Contact

This manual was created with due diligence. We hope that it will be helpful to the user to get the most out of the GPS module.

Inputs regarding errors or mistaken verbalization and comments or proposals to Maestro Wireless Solutions, for further improvements are highly appreciated.



www.maestro-wireless.com

Email: contact@maestro-wireless.com

Tel: (+852) 2869 0688

Fax: (+852) 2525 4701

Address: Room 3603-3609, 36/F, 118 Connaught Road West, Sheung Wan, Hong Kong

7.2 Related Documents

- SiRF_NMEA_Reference_Manual_2.2 (CSR)
- SiRF_Binary_Reference_Manual_2.4 (CSR)
- GPS Receiver A1080A (Maestro Wireless Solutions)
- GPS Evaluation Kit EVA1080A (Maestro Wireless Solutions)
- GPS Receiver A1084 (Maestro Wireless Solutions)
- GPS Evaluation Kit EVA1084 (Maestro Wireless Solutions)
- GPS Receiver A1088 (Maestro Wireless Solutions)
- GPS Evaluation Kit EVA1088 (Maestro Wireless Solutions)

- GPS Receiver A1035-H (Maestro Wireless Solutions)
- GPS Evaluation Kit EVA1035-H (Maestro Wireless Solutions)

7.3 Related Tools

- GPS Cockpit (Maestro Wireless Solutions)
- SiRF Live (CSR)
- SiRF Flash (CSR)